



### Instructions

1. Print this document on a piece of paper and cut out both wheels. Use thick/stiff paper if possible
2. Use a needle to make a hole in the center of both wheels. Place the smaller wheel on top of the larger one and fasten them together with a brad.
3. Voila! Your exposure wheel is ready. Use the EV marker on the inner wheel and set it to the appropriate value on the outer wheel (EV values in red). You can use the ISO markers to offset the wheel when using a different ISO than 100.

### More info on Exposure values

[http://en.wikipedia.org/wiki/Exposure\\_value](http://en.wikipedia.org/wiki/Exposure_value)  
<http://www.fredparker.com/ultexp1.htm>

